


**QUICK GUIDE**



**MODE SELECTION**

You can choose to run your Halo Air in auto, manual or off mode.

**Auto:** runs your heating to pre-set scheduled times and temperatures.

**Manual:** You control the temperature by physically turning the dial.

**Off:** Your heating will be set to a low temperature (default 8°C) for frost protection.

Move between Auto, Manual and Off modes using the right hand side button, scroll down the menu using the dial and push to select.



Use the dial to scroll between the different modes (Auto, Manual and Off) and then push the dial or press the right hand button to confirm your selection.

**TOP TIP:**

'Auto' will keep your house warm 24/7, but help you use less energy when you don't need it, this is done through 'Comfort' and 'Setback' target temperatures. The 'Comfort' temperature could be used for when you want your house to be warmer. The 'Setback' temperature is for when you would like for your house to be cooler.

## OVERRIDE OR PLUS HOURS

If you are running a schedule with pre-set times (Auto mode) and you want to adjust the temperature of your heating temporarily then turn the dial to the required temperature. If you want to keep the current temperature instead of moving the next scheduled setting then push the dial.

In both cases a pop up menu will appear for you to select how long you want to either change the temperature for, or maintain the temperature for. Simply turn the dial and push to make your selection.

The home-screen will now display the override icon above the target temperature.

Turn the dial to temporarily adjust the temperature



Press and hold the dial to extend the current heating setting.



Turn the dial to select how long you would like to extend your heating for.



The home screen will now display the override icon above the current temperature.

## SCHEDULES

Your Halo Air will come with a pre-set schedule:

6:00 **Comfort**  
8:00 **Setback**  
16:00 **Comfort**  
22:00 **Setback**

You can alter this schedule by entering the "timed heating schedule" section in the main menu.



Turn the dial to move between the different days and view the schedule that is set. To edit a day, push the dial or right hand button when the day is highlighted in light blue.



Push the dial to edit a heating time when it is highlighted in light blue. You can also add an additional heating period by scrolling and pushing on the "Add new heating event" bar. You can have up to 6 heating events per day in your schedule.



Alter the start and end times of the heating period by scrolling and then pushing the dial to edit. Then use the dial to alter the time or temperature and push to confirm. Push the dial or the right hand button to save your changes.

### TOP TIP:

Schedules help to balance comfort and energy efficiency, so you are heating your home to suit your lifestyle. Don't forget you could set your weekend schedules differently to during the week if your routine changes.